

# इंटरनेट

# मानक

## Disclosure to Promote the Right To Information

Whereas the Parliament of India has set out to provide a practical regime of right to information for citizens to secure access to information under the control of public authorities, in order to promote transparency and accountability in the working of every public authority, and whereas the attached publication of the Bureau of Indian Standards is of particular interest to the public, particularly disadvantaged communities and those engaged in the pursuit of education and knowledge, the attached public safety standard is made available to promote the timely dissemination of this information in an accurate manner to the public.

“जानने का अधिकार, जीने का अधिकार”

Mazdoor Kisan Shakti Sangathan

“The Right to Information, The Right to Live”

“पुराने को छोड़ नये के तरफ”

Jawaharlal Nehru

“Step Out From the Old to the New”

IS 5425-5 (1987): Methods of chemical analysis of misch metal, Part 5: Determination of carbon [MTD 7: Light Metals and their Alloys]



“ज्ञान से एक नये भारत का निर्माण”

Satyanarayan Gangaram Pitroda

“Invent a New India Using Knowledge”



“ज्ञान एक ऐसा खजाना है जो कभी चुराया नहीं जा सकता है”

Bhartrhari—Nitiśatakam

“Knowledge is such a treasure which cannot be stolen”



BLANK PAGE



IS : 5425 ( Part 5 ) - 1987

*Indian Standard*

**METHOD OF  
CHEMICAL ANALYSIS OF MISCH METAL  
PART 5 DETERMINATION OF CARBON**

UDC 669.85/.86 : 543.842

© Copyright 1988

**BUREAU OF INDIAN STANDARDS**  
MANAK BHAVAN, 9 BAHADUR SHAH ZAFAR MARG  
NEW DELHI 110002

*Indian Standard*METHOD OF  
CHEMICAL ANALYSIS OF MISCH METAL

## PART 5 DETERMINATION OF CARBON

Methods of Chemical Analysis of Non-Ferrous Metals  
Sectional Committee, SMDC 34

*Chairman*

DR CH VENKATESWARLU

*Representing*

Bhabha Atomic Research Centre, Bombay

*Members*

SHRI J. BANERJEE

Steel Authority of India Ltd (Durgapur Steel Plant), Durgapur

SHRI A. C. MALLICK (*Alternate*)  
CHEMIST AND METALLURGIST,  
NORTHERN RAILWAY, LUCKNOW

Ministry of Transport (Department of Railways)

ASSISTANT RESEARCH OFFICER (MET)-2

RDSO, LUCKNOW (*Alternate*)

SHRI D. P. JAIN

Saru Smelting Pvt Ltd, Meerut

SHRI R. D. RASTOGI (*Alternate*)

SHRI A. N. KAMADE

Kamani Metals and Alloys, Bombay

SHRI B. P. MAHAPATRA

Directorate General of Ordnance Factories  
CalcuttaSHRI R. N. ROY (*Alternate*)

SHRI D. D. MISHRA

Hindustan Aluminium Corporation Ltd, Mirzapur

SHRI K. C. MODI (*Alternate*)

SHRI R. N. MISHRA

Hindustan Copper Ltd, Khetri Nagar  
National Metallurgical Laboratory (CSIR),  
Jamshedpur

DR L. P. PANDEY

SHRI K. K. GUPTA (*Alternate*)

DR D. C. PRASHAR

National Physical Laboratory (CSIR), New  
DelhiSHRI J. RAI (*Alternate*)

SHRI B. R. RAI

Cominco Binani Zinc Ltd, Binanipuram

SHRI N. SRINIVASAN (*Alternate*)

SHRI M. RAE

National Test House, Calcutta

SHRI A. K. DUTTA GUPTA (*Alternate*)

DR J. RAJARAM

Essen &amp; Co, Bangalore

SHRI S. SUDARAKRISHNAN (*Alternate*)

(Continued on page 2)

© Copyright 1988

BUREAU OF INDIAN STANDARDS

This publication is protected under the *Indian Copyright Act* (XIV of 1957) and reproduction in whole or in part by any means except with written permission of the publisher shall be deemed to be an infringement of copyright under the said Act.

( Continued from page 1 )

*Members*

*Representing*

DR B. R. L. ROW	Hindustan Zinc Ltd, Udaipur
SHRI B. L. GUPTA ( Alternate )	
SHRI A. K. ROY	Bharat Aluminium Company Ltd, New Delhi
SHRI K. P. MUKHERJEE ( Alternate )	
SHRI R. K. SAWANT	Indian Standard Metal Co Ltd, Bombay
SHRI N. R. MANIAB ( Alternate )	
DR P. D. SHARMA	Hindustan Copper Ltd, Ghatshila
SHRI D. C. MATHUR ( Alternate )	
SHRI J. R. SIL	Ministry of Finance ( Indian Government Mint ), Bombay
SHRI R. P. SINGHAL	Indian Smelting & Refining Company Ltd, Bombay
SHRI A. M. DOSHI ( Alternate )	
SHRI K. RAGHAVENDRAN, Director ( Struc & Met )	Director General, BIS ( <i>Ex-officio Member</i> )

*Secretaries*

SHRI JAGMOHAN SINGH  
Deputy Director ( Metals ), BIS  
SHRI M. L. SHARMA  
Assistant Director ( Metals ), BIS

*Indian Standard***METHOD OF  
CHEMICAL ANALYSIS OF MISCH METAL****PART 5 DETERMINATION OF CARBON****0. FOREWORD**

**0.1** This Indian Standard (Part 5) was adopted by the Indian Standards Institution on 16 January 1987, after the draft finalized by the Methods of Chemical Analysis of Non-Ferrous Metals Sectional Committee had been approved by the Structural and Metals Division Council.

**0.2** Misch metal is an alloy of rare earth metals and is used for improving strength, fluidity and other properties of cast iron, steel, aluminium, magnesium and nickel alloys to which it is added. Chemical analysis of misch metal is covered in parts. In this part, a method for determination of carbon has been covered. Other parts are:

- Part 1 Determination of cerium
- Part 2 Determination of rare earths
- Part 3 Determination of iron
- Part 4 Determination of aluminium

**0.3** In reporting the result of a test or analysis made in accordance with this standard, if the final value, observed or calculated, is to be rounded off, it shall be done in accordance with IS : 2-1960\*.

**1. SCOPE**

**1.1** This standard (Part 5) covers the method for determination of carbon in various grades of misch metal as specified in IS : 4182-1967†

**2. QUALITY OF REAGENTS**

**2.1** Unless specified otherwise, analytical grade reagents and distilled water ( see IS : 1070-1977‡ ) shall be employed in the test.

---

\*Rules for rounding off numerical values ( revised ).

†Specification for misch metal.

‡Specification for water for general laboratory use ( second revision ).

### 3. DETERMINATION OF CARBON BY DIRECT COMBUSTION METHOD

**3.1 Outline of the Method** — Carbon is oxidized to carbon dioxide by combustion in an atmosphere of oxygen and absorbed by ascarite. From the gain in mass of ascarite, the carbon content is calculated. As low as 0.05 percent carbon may be determined.

#### 3.2 Apparatus and Reagents

**3.2.1 Apparatus** — As shown in Fig. 1.

**3.2.1.1 Combustion apparatus** — A mullite combustion tube heated in an electric furnace *E* heated by glow-bar going up to a temperature of 1 100°C in stages.

**3.2.1.2 Boats *F*** — Aluminium boats are heated to 1 000°C and allowed to cool in a desiccator before use.

**3.2.1.3 Oxygen purification system** — The oxygen gas first passes through concentrated sulphuric acid (*B*) and then through carbon dioxide absorbing tower (*C*) consisting of soda asbestos at the bottom and anhydron at the top.

**3.2.1.4 Absorbing tower** — The tower (*L*) is filled with ascarite at the bottom and with anhydron at the top.

**3.2.1.5 U-tubes** — Two U-tubes, one filled with zinc shots (*G*), and another with anhydron (*K*).

**3.2.1.6 Traps** — One is filled with concentrated sulphuric acid saturated with chromic acid (*H*) and the other with concentrated sulphuric acid (*J*).

#### 3.3 Procedure

**3.3.1** Take about 5 g of sample in a beaker, wash with redistilled water thrice and then with analytical grade acetone thrice to remove any organic impurities on the surface. Keep sample in an oven for about 3-4 hours at 110°C.

**3.3.2** Meanwhile switch on the furnace and raise the temperature slowly to 1 100°C and maintain at this temperature for an hour.

**3.3.3** Open the stop cocks on *C*, *G*, *K* and *L* first. Then open the cylinder carefully to allow oxygen to pass through the apparatus at a rate of about 30 ml per minute (see Note).

NOTE — Ensure that there is no back suction during oxidation.






FIG. 1 APPARATUS FOR DETERMINATION OF CARBON

**3.3.4** After half an hour, disconnect the tower *L* closing the stop cock at the U-tube (*K*) first and then the stop cock at the top of tower (*L*). Clean the outside surface of tower with tissue paper and weigh ( $M_1$ ).

**3.3.5** Connect the tower (*L*) back. Introduce the boat (3.2.1.2) into the hot zone of the mullite tube by opening at its mouth, in the minimum time possible (less than half a minute). Avoid touching the boat with hands. Connect back the oxygen flow through the mullite tube. Allow the gas to flow under these conditions for 30 minutes.

**3.3.6** Disconnect the tower *L* and weigh ( $M_2$ ) as in 3.3.4. The blank ( $M_2 - M_1$ ) should be less than 1.0 mg.

**3.3.7** Meanwhile remove the boat from the furnace and connect back the oxygen flow.

**3.3.8** Weigh 2.500 g sample and spread it in another boat.

**3.3.9** Connect the tower (*L*) back and then introduce the boat with sample into the hot zone of the combustion tube, close the tube and pass oxygen gas for half an hour as in 3.3.5. Watch the tower *H* or *J*. A lower pressure in the furnace side indicates rapid consumption of oxygen. If this is leading to the entrance of concentrated sulphuric acid into U-tube (*G*), remove the stopper on *G* and proceed as in 3.3.11 and 3.3.12.

**3.3.10** Disconnect the tower (*L*) and weigh ( $M_3$ ) as in 3.3.4. Whenever, this tower is not connected in the apparatus, it is kept in a desiccator.  $M_3 - M_2$  gives the mass of  $\text{CO}_2$  liberated.

**3.3.11** Remove the boat from the furnace and ensure for the complete combustion of the sample.

**3.3.12** Switch off the furnace. Close the oxygen flow from the cylinder. Close stop cocks on *C*, *G* and *K*.

### 3.4 Calculation

$$\text{Carbon, percent} = [ (M_3 - M_2) - (M_2 - M_1) ] \times 10.91$$

where

$M_3 - M_2$  = mass of carbondioxide found, and

$M_2 - M_1$  = mass of carbondioxide found in blank.

# BUREAU OF INDIAN STANDARDS

## Headquarters:

**Manak Bhavan, 9 Bahadur Shah Zafar Marg, NEW DELHI 110002**

**Telephones: 331 01 31, 331 13 75**

**Telegrams: Manaksanstha**

**( Common to all Offices )**

## Regional Offices:

**Telephone**

\*Western : Manakalaya, E9 MIDC, Marol, Andheri (East),  
BOMBAY 400093

**6 32 92 95**

†Eastern : 1/14 C.I.T. Scheme VII M, V.I.P. Road, Maniktola,  
CALCUTTA 700054

**36 24 99**

Northern : SCO 445-446, Sector 35-C,  
CHANDIGARH 160036

**{ 2 18 43  
3 16 41**

Southern : C.I.T. Campus, MADRAS 600113

**{ 41 24 42  
41 25 19  
41 29 16**

## Branch Offices:

'Pushpak', Nurmohamed Shalkh Marg, Khanpur, AHMADABAD 380001

**{ 2 63 48  
2 63 49**

Peenya Industrial Area 1st Stage, Bangalore-Tumkur Road,  
BANGALORE-560058

**{ 38 49 55  
38 49 56**

Gangotri Complex, 5th Floor, Bhadbhada Road, T.T. Nagar,  
BHOPAL 462003

**6 67 16**

Plot No. 82/83, Lewis Road, BHUBANESHWAR 751002

**5 86 27**

53/5, Ward No. 29, R. G. Barua Road, 5th Byelane, GUWAHATI 781003

**—**

5-8-56C L. N. Gupta Marg (Nampally Station Road), HYDERABAD 500001

**23 10 83**

R14 Yudhister Marg, C Scheme, JAIPUR 302005

**{ 6 34 71  
6 98 32**

117/419 B Sarvodaya Nagar, KANPUR 208005

**{ 21 68 76  
21 82 92**

Patliputra Industrial Estate, PATNA 800013

**6 23 06**

Hantex Bldg (2nd Floor), Rly Station Road, TRIVANDRUM 695001

**7 66 37**

## Inspection Offices (With Sale Point):

Pushpanjali 205-A West High Court Road, Bharampeth Extension,  
NAGPUR 440010

**2 51 71**

Institution of Engineers (India) Building, 1332 Shivaji Nagar, PUNE 411005

**5 24 35**

\*Sales Office in Bombay is at Novelty Chambers, Grant Road,  
Bombay 400007

**89 05 28**

†Sales Office in Calcutta is at 5 Chowringhee Approach, P.O.  
Prinsep Street, Calcutta 700072

**27 68 00**